



PollyTee™ Service Connectors Installation Instructions



A. Drill hole using appropriate core bit. Ensure hole is cut 90° to the pipe axis.



B. Lightly file pipe edges to clear away debris around the opening.



C. Remove clamp. Fold gasket in half and place into opening..



D. Pull gasket upwards until all edges of bottom flange are secure against inside pipe wall. Replace clamp.



E. Mark incoming lateral pipe, according to insertion depth. Lubricate pipe & gasket.



F. Push/press lateral pipe downward until it butts up against internal pipe stop. Tighten clamp(s) to 60 in/lbs.

